# Customizable features

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. Programming of these preferences can be performed by your Lexus dealer.

It is also possible to customize certain vehicle features yourself using the multi-information switches and the navigation screen.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

## Customizing vehicle features

It is possible to customize certain vehicle features using the multi-information switches.\*


When customizing vehicle features, ensure that the vehicle is parked in a safe place with the shift lever in P and the parking brake set.



Press and hold the menu switch of the multi-information switches to display customization mode.



- Press the "ENTER" switch upwards or downwards to select the item to be customized.
- Press the "ENTER" switch to confirm.



- Press the "ENTER" switch upwards or downwards to select the desired setting for the item being customized.
- Press the "ENTER" switch to confirm.

When customization is completed, press the menu switch to clear the customization screen.

\*: For instructions on customizing vehicle features using the navigation screen, refer to the "Navigation System Owner's Manual".

### Customizable Features

- Vehicles with a navigation system: Settings that can be changed using the screen of the navigation system
- Vehicles with a navigation system: Settings that can be changed using the multi-information switches
- Sehicles without a navigation system: Settings that can be changed using the multi-information switches
- A Settings that can be changed by your Lexus dealer Definition of symbols: O = Available, = Not available

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Door lock (→P. 46, 586)	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	-	-	0
	Speed-detect- ing automatic door lock func- tion	Off	On	0	-	0	0
	Shifting gears to position other than P locks all doors	On	Off	0	-	0	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Door lock (→P. 46, 586)	Shifting gears to P unlocks all doors	On	Off	0	_	0	0
	Opening driver's door unlocks all doors	Off	On	0	-	0	0
Smart access sys- tem with push-button	Operation signal (buzzer)	7	Off 1 to 6	0	_	0	0
	Operation signal (Emergency flashers)	On	Off	0	_	0	0
start and	Time elapsed		Off				
wireless remote con- trol	before the auto- matic door lock function is acti-	60 sec-	30 sec- onds	0	_	0	0
$(\rightarrow P. 31, 42)$	vated if a door is not opened after being unlocked	onds	120 sec- onds		, –		
Smart access system with push-button start (→P. 31)	Smart door unlocking	Driver's door	All the doors	0	_	0	0
	Smart access system with push-button start	On	Off	0	-	0	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Power back door (→P. 50)	Power back door opening operation using the back door opener button	Off	On	_	_	_	0
Wireless remote control (→P. 42)	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	-	0	0
			Off			0	
	Time elapsed before the head-	30 sec-	60 sec- onds	0	-		0
Automatic light control system (→P.182)	lights turn off	onas	90 sec- onds				
	Light sensor sensitivity	Standard	-2 to 2	0	-	0	0
	Daytime run- ning light system	On	Off	0	-	0	0
	Automatic high beam system	On	Off	-	_	-	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
			Off				
	Time elapsed before the inte-	15 seconds	7.5 sec- onds	0	_	0	0
	rior lights turn off		30 sec- onds				
			Off		_		
	Time elapsed before the exte-	15 seconds	7.5 sec- onds	0 - 0	0	0	
Illumination (→P. 400)	rior lights turn off		30 sec- onds				
	Sensitivity of the ambient light sensor used for dimming the meter lights etc.	Standard	-2 to 2	0	_	_	0
	Sensitivity of the ambient light sensor used for brightening the meter lights etc.	Standard	-2 to 2	0	_	_	0
	Footwell lighting	On	Off	-	_	_	0
	Outer foot lights	On	Off	_	-	-	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Automatic air condi- tioning sys- tem (→P. 278)	Switching between outside air and recircu- lated air mode linked to "AUTO" switch operation	Auto	Manual	0	-	-	0
	A/C auto switch operation	Auto	Manual	0	-	-	0
	Exhaust gas sensor sensitivity	Standard	-3 to 3	0	_	_	0
	Driver's seat		Off				
Front seats (→P. 60)	movement when exiting the vehicle (on some models)	Full	Partial	0	-	0	0
Multi-infor- mation dis- play (→P. 171)	Eco Driving Indi- cator Light	On	Off	-	0	0	0
Power windows (→P. 89)	Mechanical key linked operation	On	Off	-	-	-	0
	Wireless remote control linked operation	On	Off	_	-	-	0

## 6-2. Customization

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Moon roof (→P. 92)	Mechanical key linked operation	On	Off	-	-	-	0
	Wireless remote control linked operation	On	Off	-	-	-	0
Intuitive parking assist (→P. 218)	Buzzer volume	3	1 to 5	0	-	-	0
	Detection dis- tance of the rear center sensor	Far	Near	0	-	-	0
	Display setting (when intuitive parking assist is operating)	All sensors displayed	No sensor displayed	0	_	_	0

## Multi-information display ( $\rightarrow$ P. 171)

Settings that can be changed using the multi-information switches

Available units

miles (MPG), km (km/l), km (l/100 km)

Available languages

English, French and Spanish

- In the following situations, customize mode will automatically be turned off.
  - A warning message appears after the customize mode screen is displayed.
  - The "ENGINE START STOP" switch is turned off.
  - The vehicle begins to move while the customize mode screen is displayed.

# **A** CAUTION

### ■ Cautions during customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

# ♠ NOTICE

### During customization

To prevent battery discharge, ensure that the engine is running while customizing features.